


677/50  
677/70  
677/100



- I** ISTRUZIONI D'USO
- GB** INSTRUCTIONS FOR USE
- F** MODE D'EMPLOI
- E** INSTRUCCIONES DE USO
- D** BEDIENUNGSANLEITUNG


M2099528

BETA UTENSILI S.p.A.  
via Alessandro Volta, 18 - 20050 Sovico - MILANO (ITALY)  
Tel. +39 039.2077.1 - Telefax +39 039.2010742  
www.beta-tools.com - info@beta-tools.com




1

**Regolare - Adjust - Régler - Ajustar - Einstellen**



2

**Spingere al centro dell'impugnatura  
Push from the centre of the handle  
Appuyez au centre de la poignée  
Accionar desde el centro del mango  
Betätigung nur von der Handgriffmitte**



**Punti di lubrificazione  
Lubrification points  
Points de graissage  
Puntos de lubricacion  
Schmierstellen**